

INSTALLATION INSTRUCTIONS

PREPARATION

Check that your support is dry and in good condition before installing your plate. Scrap away the paint, remove old wallpaper. Do not glue onto unstable support (wood, metal, ceramics, damp places), or exposed to temperatures over 50°C.

In your box, there is a great variety of models and shades. You are advised to mix the plates from several boxes. We also advise you to buy the amount necessary for the job all at once (our products evolve with the time and age over the years).

For most references, corner stones are available, check with our Customer Service for more details and sales points.

The corner stones, door and window framing, skirting boards, plate rails and cornices must be installed before the flat parts to avoid unsightly cuts.

INSTALLATION

1. Trace out lines every 50cm. You are advised to work from the top to the bottom to avoid stains.
2. As necessary, remove excess material behind the plates using a wood rasp.
3. Apply the MODULOCOLLE (interior) or COLLE EXTRA (“interior/exterior” or “exterior” products) points behind the plates. You can also work in double gluing (support + plates). Double gluing is compulsory for “interior/exterior” and “exterior” products.
4. Apply them to the wall by pressing and a horizontal back-and-forth movement, leaving a space between them.
5. These plates can very easily be cut with a saw. The wood rasp and the crown saw may be used for particular cuts (switch/socket, etc). To respect the character of rustic style plates, it is preferable to break them rather than saw them.
6. Depending on the chosen plate, do the joint with MODULOJOINT or JOINT A L’ANCIENNE 24 hours after installation.
7. Prepare the mortar, cut the end of the bag diagonally (2 to 3 cm), fill the bag half full, by pressing fill the joints to the brim by holding the bag at the bottom of the groove in contact with the wall. If it overflows onto the stones, let it set and remove the excess at the final scraping.
8. As soon as the mortar begins to set (± 1 hour), clamp the joint using a tuck pointer.
9. To finish, the regular joints must be smoothed with the tuck pointer, the others are to be brushed with a brush (do not use a metal brush or a sponge)
10. To protect your plates from any splashing of water, apply the water and oil repellent MODULO PROTECTION PLAQUETTES DE PAREMENT spray.

It is advised to work by section of about 3m².